

RPP Oil Extension Tube Guide:

RPP3:1 and RPP5:1 Standard Pumps Include:

- ET10000 Extension.
- The ET10000 extension includes: two lengths of tube; 8" (short) and 20" (long) plus a foot valve and a strainer. Total length of ET10000 is 32".
- The ET100000 includes a ET10200 that is 8" and a ET10500 that is 20".
- ** Always use the Foot valve on lowest point of stub or extension. Foot valve on stub must be removed to attach extensions.

Extension Combinations and Lengths:

RPP3:1 and 5:1 oil pump stub length with the foot valve and strainer = 6" to 9" below the tank seal.

- RPP3:1 and 5:1 oil pump stub with the ET10000 extension length = 34" to 37" below the tank seal.**
- RPP3:1 and 5:1 oil pump with ET10000 add ET10000-2 (ET10000 and ET10002) = 63" to 66" below seal.**
- RPP3:1 and 5:1 oil pump with ET10000 add ET10002 and ET10500 = 54" to 57" below seal.**
- RPP3:1 and 5:1 oil pump with ET10000 add ET10002 and ET10200 = 42" to 45" below seal.**
- RPP3:1 and 5:1 oil pump with ET10000 replace ET10200 included in ET10000 with ET10500 = 46"-49".**
- RPP3:1 and 5:1 oil pump with ET10000 replace ET10500 included in ET10000 with ET10200 = 22"-25"***

Bulk Oil Container Depths:

- 16 Gallon Drum – 26" seal to sump measurement
- 30 Gallon Drum – 27" seal to sump measurement
- 55 Gallon Drum – 33.5" seal to sump measurement
- 275 Gallon Cage Tank – 38.75" seal to sump measurement
- 330 Gallon Cage tank – 47" seal to sump measurement

